

Mounting instructions

Dry mounting of contour cut and applied film.

1. Clean the mounting location thoroughly with alcohol on a lint-free cloth/paper. It is important that all surfaces, edges and mouldings are cleaned well. A clean surface makes for neat mounting. This technique can be performed by one person. For large items, it is useful to have two people for this technique.
2. Put masking tape on the top area of the media on the desired location. Afterwards you can adjust the right and left side. Secure the middle and bottom with masking tape.
3. Lift the media to the centre and gently pull off the backing. Cut the backing off. Keep the media stretched out while lifting it back.
4. One person scrapes the film while another holds the media outstretched. Start from the middle and scrape up and down.
5. Remove all masking tape from the media. Lift the last piece to the middle and gently pull the backing from the media.
6. Keep the media stretched out while lifting it back. Start from the middle and scrape up and down. One person holds the media outstretched while the other scrapes the film.
7. Then remove the application paper. Pull from the top left towards the bottom right

