

Mounting instructions

Mounting streamers in water on windows, painted panels and flat surfaces.

1. Clean the mounting location thoroughly with alcohol on a lint-free cloth/paper.
2. Mix water with three drops of detergent in a spray bottle. Spray the mounting location with the mixture.
3. Place the film face down on the wet surface so that the backing paper is facing you. Then peel off the backing paper from one corner.
4. Spray the entire adhesive side with your soap mixture until it is completely wet.
5. Turn the film so that the glue side is facing the mounting location and place the streamer.
6. Then scrape out the water thoroughly with a window scraper. Start from the top and work your way to the bottom.
7. Gently wipe away excess water with a dry cloth.

